
- $\begin{array}{lll} A = & height from floor to chimney connection upwards \\ B = & height from floor to c/c chimney connection rear \\ C = & height from floor to air inlet \\ D = & height from floor to lower edge of hatch \\ \end{array}$



- \* If the stove is placed on a hearth plate made of glass for example (accessory), the height from the floor is affected by a distance corresponding to the thickness of the hearth plate, for a free standing glass hearth plate this is 10 mm.
- \*\* To prevent discolouration of painted non-flammable walls we recommend that the same side distance as to combustible walls is used.